

TFBE037



TFBE037 Two liner transfer tape used to add adhesive to the substrate of your choice. Print on to the face and back of a window decal and then laminate adhesive over the print. Laminate the adhesive to the printed side of a clear film to protect the print from UV rays and/or other exposures. The clear liner is ideal when showing off high color prime labels.

SL01055 42# SCK Liner Premium Easy Release

TC50602 #720 AT High Tack Perm

SLF3037 1.5 CPET with silicone - easy release

Ship Date:	Min Order:	Master Width:	Liner Caliper:	Overall Caliper:	Shipping Weight:
1 week	1,000 msi	54"	1.5 mils	4.5 mils	218#/mmsi